HILLSLOPE DELINEATION TOOLBOX USER MANUAL

User Manual for the ArcGIS 10 Hillslope Delineation Toolbox

Prepared for

USDA Forest Service Rocky Mountain Research Station Forestry Sciences Laboratory 1221 South Main Street Moscow, Idaho 83843

Prepared by

Herrera Environmental Consultants 2200 Sixth Avenue, Suite 1100 Seattle, Washington 98121 Telephone: 206.441.9080

March 30, 2012

Note:

Some pages in this document have been purposely skipped or blank pages inserted so that this document will copy correctly when duplexed.

Contents

System Requirements	1
System Requirements Summary	2
Hillslope Delineation Toolbox Installation	2
Installation Steps Preparing ArcMap for Toolbox Use	
Using the Hillslope Delineation Toolbox	8
Data Gathering	8
Step 1: Hydrology Processing	
Implementation of Hydrology Processing	
Step 2: Stream and Watershed Delineation	
Implementation of Stream and Watershed Delineation	
Step 3A: Disturbed WEPP Treatment Area Processing	. 16
Implementation of Disturbed WEPP Treatment Area Processing	
Step 3B1: ERMiT Treatment Area Processing	. 18
Implementation of ERMiT Treatment Area Processing	. 18
Step 3B2: ERMIT Burn Severity Processing	. 20
Step 4: Representative Slope Profile Extraction	. 21
Implementation of Representative Slope Profile Extraction	. 21
Step 5: Process Representative Slope Profile	. 23
Implementation of Process Representative Slope Profile	. 23
Step 6: Export Hillslope Data	
Implementation of Export Hillslope Data	. 25
Step 7: Export Hillslope CSV File	. 28

Appendix A Toolbox User Resources

Tables

Table 1.	Formatted hillslope output table fields	j
10010 11		

System Requirements

The Hillslope Delineation Toolbox is a custom set of tools developed to be used with GIS technology and requires two pieces of software to function successfully: ESRI ArcGIS 10 and the ArcGIS Spatial Analyst extension. You will be unable to use the toolbox without both pieces of software installed and licensed on your machine.

The Hillslope Delineation Toolbox was developed to run in ArcGIS 10 only. If you are unsure of what version of ArcGIS you are running, please see your system administrator or check your **ArcGIS Administrator** program. To start the **ArcGIS Administrator**, make sure all ESRI programs are closed, and then click:

💐 ArcGIS Administrator	
ArcGIS (COMP-167) C Desktop C Availability D Desktop D Desktop	ArcGIS Configuration Information: DESKTOP Product Name: ArcGIS Desktop 10. Release Version: 10.0.4.4000 Installation Folder: C:\Program Files\ArcGIS\Desktop10.0\ Install Date: 3/26/2012 Install Time: 9:50:51 Install Image: 0:\departments\Gis\Software\ArcGIS_vers10\ArcGIS_D Current User: jschmidt Application Data Folder: C:\Documents and Settings\jschmidt\Applicatio System Temporary Folder: C:\DocUME~1\jschmidt\LOCALS~1\Temp\ Pervice Pack Information ArcGIS Service Pack Install Date: 3/26/2012 ArcGIS Service Pack Install Date: 3/26/2012 ArcGIS Service Pack Install Time: 9:50:51 ArcGIS Service Pack Status: N/A Leense Manager Environment Variable Information Application Inferment ArcGIS LICENSE_FILE: N/A
	OK Cancel Apply

Start->All Programs->ArcGIS->ArcGIS Administrator

jr 10-04818-000 hillslope toolbox user guide - arcgis 10

To see if the Spatial Analyst extension has been installed and registered, click on the Availability folder and look for Spatial Analyst in the software window.

ktop Availability This lis Borrow/Return date.	l itor (Single Use) ts the software installe Double-click a feature			status and exp	iratior
a Licenses	oftware	Installed	Authorized	Expires	~
Ar	cEditor	Yes	Yes	permanent	
	etwork Analyst	Yes	No	N/A	
) Analyst	Yes	Yes	permanent	
	atial Analyst	Yes	Yes	permanent	
	eostatistical Analyst	Yes	No	N/A	
	ıblisher	Yes	No	N/A	
	acking Analyst	Yes	No	N/A	
	aplex	Yes	No	N/A	
	ata Interoperability	No	No	N/A	
	cScan	Yes	No	N/A	
	isiness Analyst	No	No	N/A	
	isiness Analyst Pre	No	No	N/A	
	hematics	Yes	No	N/A	
07	BA	Yes	No	N/A	
	orkflow Manager	No	No	N/A	
	oduction Mapping	No	No	N/A	
0.72		2322			_
1.05				the second se	~
De Na	ata Reviewer efense Mapping autical telligence Agency Refresh	No No No No	No No No	N/A N/A N/A N/A	

System Requirements Summary

- **ESRI ArcGIS 10**
- . Spatial Analyst Extension

All other system requirements are the same for the Hillslope Delineation Toolbox as they are for the ArcGIS software package. For a complete list of ArcGIS 10 system requirements, please visit the following website: http://resources.arcgis.com/content/arcgisdesktop/10.0/arcgis-desktopsystem-requirements.

Hillslope Delineation Toolbox Installation

The Hillslope Delineation Toolbox runs inside the ArcGIS software and is very easy to install with a few quick steps. It is not a stand-alone program and has no executable file associated with it.

2

Installation Steps

- 1. Right-click on the Hillslope Delineation Toolbox zip file and click on **Extract All**. This brings up the **Windows Extraction Wizard**.
- 2. Click **Next**.
- 3. Change the extraction directory to:

C:\Documents and Settings\[User_Name]\Application Data\ESRI\Arc Toolbox\My Toolboxes

Make sure that you change **[User_Name]** to your Windows Login name. If you choose to save the file to a different directory, make sure to note the location for later.

Extraction Wizard	
Select a Destination Files inside the ZIP a choose.	archive will be extracted to the location you
	Select a folder to extract files to. Files will be extracted to this <u>directory</u> :
	Application Data\ESRI\ArcToolbox\My Toolboxes
	Browse
P	Password
201	Extracting
	< <u>B</u> ack <u>N</u> ext > Cancel

- 4. Click **Next**.
- 5. Uncheck **Show extracted files** and click **Finish**.
- 6. Start the ArcMap Program by clicking Start→All Programs→ArcGIS→ArcMap 10.

jr 10-04818-000 hillslope toolbox user guide - arcgis 10


7. Click on the icon to open **ArcToolbox.**



- 8. Right-click anywhere in the empty white space in **ArcToolbox** and select **Add Toolbox**.
- 9. Navigate to the location where you saved the toolbox in Step 3, select the **Hillslope Delineation Tools Toolbox**, and click **Open**.

Add Toolbox			×
Look in: 🔲 My Toolboxes		- 🕒 😒 🛚	
Name	Туре		<u>~</u>
Stoolbox 5	Toolbox		
Models	Toolbox		
Some Model Builder	Toolbox		
Story 3	Toolbox		
Signal Hillslope Tools	Toolbox		
Section 2 March 2015	Toolbox		
Hillslope Delineation Tools	Toolbox		
🚞 Setup	Folder		
Doc	Folder		
			~
Name: Hillslope Delineation	Tools		Open
Show of here .			
Show of type: Toolboxes			Cancel

10. Double-click on the **Hillslope Delineation Tools** toolbox inside ArcToolbox to expand the toolbox.



Preparing ArcMap for Toolbox Use

Before you can begin using the Hillslope Delineation toolbox, you must first make sure that the **Spatial Analyst** extension is both installed and activated. If any license error warnings appear while you are completing the steps below, it is possible that you either don't have **Spatial Analyst** installed on your machine or it is not currently registered. Please contact your system administrator for further assistance.

Activating Spatial Analyst

- 1. If it is not already running, start **ArcMap**.
- 2. On the main menu, click the **Customize** menu, and select **Extensions**.
- 3. Make sure that the box next to **Spatial Analyst** is checked.

Extensions	? 🛛
Select the extensions you want to use.	
☑ 3D Analyst	
ArcScan Geostatistical Analyst (Not authorized)	
Maplex	
Network Analyst (Not authorized)	
Schematics	
Spatial Analyst Tracking Analyst	
Description:	
Spatial Analyst 10.0 Copyright ©1999-2010 ESRI Inc. All Rights Reserved	
Provides spatial analysis tools for use with raster and fe	eature data.
About Extensions	Close

4. Click **Close**.

Field Name Settings

The Hillslope Delineation Toolbox is built to run many automated steps based on the names of specific fields. To make sure that the toolbox runs correctly and is properly able to identify field names even when multiple tables are joined together, it is necessary to change one general setting for ArcToolbox before you begin.

1. Right click anywhere in the empty white space of ArcToolbox, and click the **Environments** option.

🛠 Environment Settings		
* Workspace	<u>×</u>	Environment Settings
¥ Output Coordinates		
➢ Processing Extent		Environment settings specified in this dialog box are values
* XY Resolution and Tolerance		that will be applied to
seener o		appropriate results from running
× M Values		tools. They can be set
¥ Z Values		hierarchically, meaning that they can be set for the
¥ Geodatabase		application you are working in,
¥ Geodatabase Advanced		so they apply to all tools; for a
¥ Fields		model, so they apply to all
		processes within the model; or for a particular process within a
¥ Random Numbers		model. Environments set for a
¥ Cartography		process within a model will
¥ Coverage		overrride all other setting, and
× Raster Analysis		environments set for all
		processes in a model will override those set in the
¥ Raster Storage		application.
✗ Geostatistical Analysis		10. ·
¥ Terrain Dataset		Changing the default settings
¥ TIN		that will be used is a
		prerequisite to performing geoprocessing tasks. You may
		only be interested in analyzing
		a small piece of a geographic
		area, such as changing the
	OK Cancel << Hide Help	Tool Help

Click on the ${\bf Fields}$ drop-down and make sure the box next to ${\bf Maintain\ fully}$ 2. qualified field names is unchecked.

	Тор			Environment Settings
Left Snap Raster	Bottom	Right		Environment settings specified in this dialog box are values that will be applied to appropriate results from running tools. They can be set biographically, proving that
				hierarchically, meaning that they can be set for the
XY Resolution and Tolerance				application you are working in, so they apply to all tools; for a
M Values				model, so they apply to all
Z Values				processes within the model; or
Geodatabase				for a particular process within a model. Environments set for a
Geodatabase Advanced				process within a model will
Fields				overrride all other setting, and environments set for all
Maintain fully qualified field names				processes in a model will
				override those set in the application.
Random Numbers				application.
Cartography				Changing the default settings
Coverage				that will be used is a prerequisite to performing
Raster Analysis				geoprocessing tasks. You may
Raster Storage				only be interested in analyzing
Geostatistical Analysis			Ē	a small piece of a geographic area, such as changing the
Terrain Dataset			~	extent for results or you may

<u>jr</u> 10-04818-000 hillslope toolbox user guide - arcgis 10 March 30, 2012

3. Next click on the **Workspace** drop-down menu. This is where you can set the **Current Workspace** and **Scratch Workspace** environments. Click in the **Current Workspace** box and enter the location you would like to have output files generated by the Toolbox saved to. This location is for output files that you intend to maintain.

🛠 Environment Settings	
* Workspace	Current Workspace
C:\Temp\Current	Specify the workspace from
Scratch Workspace	which inputs are taken and into
C:\temp\Scratch	which outputs are placed.
Output Coordinates Output Coordinate System	
Same as Input 💌 😁	
Pri la	
Geographic Transformations	
Geographic Transformations Names	
Default 🕑	
Top	×
OK Cancel << Hide Help	Tool Help

- 4. Click in the **Scratch Workspace** box and enter the location where you would like to have intermediate files generated by the Toolbox saved to. This location is for temporary output files that you do not wish to maintain.
- 5. Click **OK**.

Using the Hillslope Delineation Toolbox

Data Gathering

The Hillslope Delineation Toolbox requires the user to obtain and input a few GIS datasets to generate output for the Disturbed WEPP and ERMiT Batch models. Listed below are the required datasets:

- An elevation raster such as a 10-meter DEM or LiDAR,
- Polygons describing treatment or vegetation types,
- Polygons describing soil textures,
- A BARC (Burned Area Reflectance Classifiation) burn severity raster (ERMiT Batch model only), and stream centerline data with names (optional).

Some of this data are publicly available for most areas, such as elevation data, stream centerlines, and soil data. Other files like treatment or vegetation type polygons will need to be generated by the user. Appendix A provides information on public data sources to help you with data gathering as well as basic instructions on creating your own data.

The data also needs to meet a couple basic requirements before it can be used successfully in the Hillslope Delineation Toolbox.

- All data needs to be in one common coordinate system.
- The elevation dataset used needs to be one single raster.
- Grid size does not need to be consistent between the elevation and BARC rasters.

Appendix A provides more information on how to preprocess data if you have multiple elevation grids or multiple coordinate systems.

The following sections provide step-by-step instructions for each tool in the Hillslope Delineation Toolbox. They also explain background terminology and any important considerations that may affect your overall model results. The tools are designed to be used in a sequential order and much of the data processing itself is hidden from the user. This is to ensure that the Hillslope Delineation Toolbox can be run by a user with minimal GIS experience without the need for any additional resources besides this user guide.

Step 1: Hydrology Processing

The first tool in the Hillslope Delineation Toolbox is **Hydrology Processing**. The purpose of this tool is to run a series of hydrology processing steps on an input elevation raster in order to generate necessary output gridsfor later steps in the toolbox. The following output files will be generated by this tool:

Clipped Elevation Grid

The first grid that is generated by the **Hydrology Processing** tool is the **Clipped Elevation Grid**. This grid is generated by clipping an input elevation raster to an extent defined by the user.

Hillshade Grid

The second grid that is generated by the **Hydrology Processing** tool is the **Hillshade Grid**. A hillshade is generated by modeling illumination source angles and shadows to create a shaded relief grid that gives the user a more three-dimensional sense of on-the-ground topography.

Fill Grid

The third grid that is generated by the **Hydrology Processing** tool is the **Fill Grid**. This grid is generated by running the **Spatial Analyst Fill** command on the elevation raster to fill any closed depressions and other surface anomalies in the elevation dataset that would affect hydrology analysis on the raster.

Flow Direction

The fourth grid generated by the **Hydrology Processing** tool is the **Flow Direction Grid**. This grid is generated by running the **Spatial Analyst Flow Direction** command on the filled elevation raster to create a raster displaying the direction every pixel drains to its steepest downslope neighbor.

Flow Accumulation

The fifth grid generated by the **Hydrology Processing** tool is the **Flow Accumulation Grid**. This is generated by running the **Spatial Analyst Flow Accumulation** command on the flow direction raster to create an ouput raster of accumulated flow at each pixel.

Implementation of Hydrology Processing

The **Hydrology Processing** tool assumes that you have already obtained one single elevation raster for your study area and are now ready to process it and generate a number of output grids for later toolbox steps. If you need help in obtaining elevation data or have more than one elevation raster that you need to combine, please see Appendix A before proceeding. If you already have your elevation dataset ready, the following steps will help you get started:

1. Open the **Hydrology Processing** tool by clicking on **Step 1: Hydrology Processing** in the Hillslope Delineation Toolbox. If yellow exclamation points occur next to any of the outputs, don't be concerned. This indicates that the file that you are trying to generate already exists. Once you choose a new file name, the exclamation point errors will disappear.

Input Elevation Grid			-	Input Elevation Grid	
		•	0	ALCO DECLEMENTS	
Input Extent Rectangle				Input an elevation DEM.	
		~	6		
	Тор				
Left		Right			
	Bottom	 			
		Clear	1		
Output Clipped Elevation Grid			·		
C:\temp\grid_clp_1			0		
Output Hillshade Grid					
C:\temp\grid_hs_1			2		
Output Fill Grid					
C:\temp\grid_fill_1			0		
Dutput Flow Direction Grid					
C:\temp\grid_fdir_1			6		
Output Flow Accumulation Grid					
C:\temp\grid_facc_1			2		
			~		
	100	 		1	

2. Click on the file folder icon next to the **Input Elevation Grid** drop-down and navigate to your elevation raster dataset.

🔭 Step 1: Hydrology Pro	cessing				
Input Elevation Grid				<u> </u>	Step 1:
dem.tif			•	2	Hydrology
Input Extent Rectangle	Y Maximum				Processing
	r maximum				
		4539238.590000			Completes the hydrology
X Minimum		X Maximum			preprocessing steps required to generate
	414639.538000		500019.538000		the grid inputs for the
	Y Minimum				next steps in this toolbox.
		4427728.590000	Clear	1	
Output Clipped Elevation Grid					
D:\Temp\grid_clp_1				2	
Output Hillshade Grid					
D:\Temp\grid_hs_1				2	
Output Fill Grid					
D:\Temp\grid_fill_1				2	
Output Flow Direction Grid					
D:\Temp\grid_fdir_1				2	
Output Flow Accumulation Gr	id				
D:\Temp\grid_facc_1				2	
				~	V
		OK Cancel I	Environments << F	lide Help	Tool Help

3. Elevation grids can be quite large depending on the geographic extent and pixel size, and large files can take up a lot of storage space and processing time. The **Input Extent Rectangle** inputs are designed to allow you to clip large elevation grids to a size that better represents your study area. You have two options for setting the extent to clip to. First, you can select an existing dataset to clip from the **Input Extent Rectangle** polygon. The other option is described in the next steps.

If you don't want to clip your elevation grid to a smaller size, leave the minimum X and Y values with their default values.

- 4. To clip your raster to a rectangle manually without using an existing dataset, use the zoom tool to zoom to the display extent you want to clip your dataset to. Be sure that the display covers the whole area that you want to analyze plus a little bit of extra area.
- 5. In the lower right hand corner of the data frame are coordinate values for the data extent. Move your cursor around in the data space to see how these values change.

Y Mini	414639.538000	4539238.590000 X Maximum	500019.538000	F P C h	Step 1: Aydrology Processing completes the ydrology reprocessing steps	
Input Extent Rectangle Y Mao X Minimum Y Mini	414639.538000			F P C h	Hydrology Processing Completes the ydrology reprocessing steps	А .
Y Max X Minimum Y Mini	414639.538000			C h	Processing Completes the ydrology reprocessing steps	А .
X Minimum J Y Mini	414639.538000		500019.538000	C h; pi	Completes the ydrology reprocessing steps	<u> 4</u>
Y Mini			500019.538000	h: pi	ydrology reprocessing steps	and the second
Y Mini		X Maximum	500019.538000	pi	reprocessing steps	三
Y Mini		X Maximum	500019.538000			
I Y Mini			500019.538000		equired to generate	
	mum				ne grid inputs for the	
					ext steps in this colbox.	
		4427728.590000	Clear	1	JUIDUX.	
		4427720.390000				
Output Clipped Elevation Grid						
D:\Temp\grid_clp_1				E		
Output Hillshade Grid						
D:\Temp\grid_hs_1						
Output Fill Grid				. al		
D:\Temp\grid_fill_1				B		
Output Flow Direction Grid						
D:\Temp\grid_fdir_1				2		
Output Flow Accumulation Grid				1.01		
D:\Temp\grid_facc_1				2		
					0	1
			r.		<u>.</u>	
		OK Cancel	Environments	iide Help	Tool Help	2
					3	9

- 6. To determine the X Minimum value for your view frame, move your cursor to the very bottom left corner of the view frame and look at the coordinate values in the bottom right of the data frame. Type the first number in the pair of coordinates in the **X Minimum** box.
- 7. Next move your cursor to the very bottom right corner of the view frame and look at the coordinate values below your cursor in the data frame. Type the first number in the pair of coordinates in the **X Maximum** box, and then type the second number in the pair into the **Y Minimum** box.
- 8. Now scroll to anywhere in the very top of the view frame. Type the second number in the pair of coordinates in the bottom right corner of the data frame into the **Y Maximum** box. These four new bounding coordinates create a box that will be used to clip your raster to the view frame extent.
- 9. Click in the **Output Clipped Elevation Grid** box to name your output file. Make sure to give the raster a meaningful name that also indicates the toolbox step number such as "grid_clp_1". Raster names cannot exceed 13 characters in length, so intuitive naming conventions are important.
- 10. Click in the **Output Hillshade Grid** box to name your output file. A suggested naming convention for this output raster is "grid_hs_1".
- 11. Click in the **Output Fill Grid** box to name your output file.. A suggested naming convention for this output raster is "grid_fill_1".
- 12. Click in the **Output Flow Direction Grid** box to name your output file. A suggested naming convention for this output raster is "grid_fdir_1".
- 13. Click in the **Output Flow Accumulation** box to name your output file. A suggested naming convention for the output raster is "grid_facc_1".
- 14. Click **OK**. After the tool is finished running, the output raster datasets will be added to the ArcMap table of contents.

Step 2: Stream and Watershed Delineation

The second tool in the Hillslope Delineation Toolbox is **Stream and Watershed Delineation**. The purpose of this tool is to use the flow accumulation and flow direction grids generated in Step 1 to generate a stream network and delineate hillslope areas draining to each stream. The following output files will be generated by this tool:

Stream Network Polylines

The first output file is a shapefile of the stream network. This is derived by combining the elevation grid output generated in Step 1 with a user-defined stream accumulation threshold area.

Both the streams and the hillslope areas delineated by this tool are sensitive to elevation grid resolution, and it is important to be aware of resolution limitations when using this tool. More detailed information about resolution limitations and stream threshold input is provided below in the tool instructions.

Hillslope Polygons

The output file from this tool is a shapefile of top, left, and right hillslope polygons. Not all hillslopes drain to streams.

Implementation of Stream and Watershed Delineation

1. Open the **Stream and Watershed Delineation** tool by clicking on **Step 2: Stream and Watershed Delineation** in the toolbox. If yellow exclamation points occur next to any of the outputs, don't be concerned. This indicates that the file that you are trying to generate already exists. Once you choose a new file name, the exclamation point errors will disappear.


Input Flow Accumulation Grid		Step 2: Stream and
Input Flow Direction Grid Input Flow Direction Grid Stream Threshold Layers and variables Plus_Watersh4 Watersh_grid5 grid_facc_1 grid_fdir_1 grid_fdir_1 grid_fdir_1 grid_fs_1	Pick SetNull Math Abs Fxn	Watershed Delineation Creates a stream centerline shapefile based on a user- defined flow accumulation threshold and delineates hillslope polygons.

- 2. Click on the **Input Flow Accumulation Grid** drop-down menu and select the flow accumulation grid that you created in Step 1.
- 3. Click on the **Input Flow Direction Grid** drop-down menu and select the flow direction grid that you created in Step 1.

4. Notice that an equation has been pre-entered in the **Stream Threshold** box. The purpose of this equation is to set a contributing drainage area limit that will determine the resolution of a polyline stream network. By default the threshold value is set to 500, which means that a stream will be defined as a connected network of pixels that have at least 500 other cells draining downslope to them. Put another way, 500 10-meter pixels is the equivalent of a contributing drainage area of 0.05 square kilometers.


Establishing appropriate stream threshold cutoff values for your study area and your raster resolution size is important. Both stream networks and hillslope areas are sensitive to resolution, and the stream threshold value that you choose has a direct impact on the size and number of hillslopes that you will generate. Fine resolution rasters such as LiDAR data can accurately generate more detailed stream networks and hillslopes draining to them than course resolution datasets can. One method for determining an appropriate cutoff value for your stream raster is to experiment with values that generate results similar to known GIS stream networks from publicly available sources such as USGS (http://nhd.usgs.gov/).

The figures below show examples of stream networks delineated using different stream threshold cutoff values and the hillslopes draining to them as well as the USGS stream delineation.



Stream threshold value of 100 pixels (0.01km2).

Stream threshold value of 500 pixels (0.05 km2).



Stream threshold value of 1000 pixels (0.1 km2).

USGS stream delineation.

To change the threshold cutoff value, click in the white **Stream Threshold** box and replace the 500 value with a cutoff value of your choice.

- 5. Click on the file folder next to the **Output Stream Network** box and navigate to the location where you would like to save the stream polyline output. A suggested naming convention for this output file is "grid_stream_network_centerlines_ step2.shp".
- 6. Click in the **Output Watershed Grid Name** to name your output file. Raster files have a limit of 13 characters or less. A suggested naming convention for this output file is "wshd_grid". It is not necessary to specify an output folder for this file and it is important to make sure that the file name does not already exist.
- 7. Click in the **Output Hillslope Polygons** to name your output file. A suggested naming convention for this output shapefile is "hillslope_polygons_step2.shp".
- 8. Click **OK**.

Step 3A: Disturbed WEPP Treatment Area Processing

The next tool in the Hillslope Delineation Toolbox is **Disturbed WEPP Treatment Area Processing**. If you would like to generate data for the ERMiT batch model instead, please skip to **Step 3B1: ERMiT Treatment Area Processing.** The purpose of this tool is to intersect the hillslope polygons created in Step 2 with treatment or vegetation type and soil texture polygons data to generate hillslope input for the Disturbed WEPP model. Optionally this tool also allows you to input named stream network polylines to determine which streams are adjacent to hillslopes. The following output files will be generated by this tool:

Disturbed WEPP Hillslope Polygons

The **Treatment Area Processing** tool has only one output file. This file is an intersection of hillslopes, treatment or vegetation type, and soil texture data. It is possible for there to be more than one hillslope in a treatment or vegetation type area. Each intersection in the output file is a hillslope polygon with a unique ID. If you choose to enter named stream network data, the name of the adjacent stream for each polygon will be included in the output file. Not all hillslopes have an adjacent stream.

If you need help in obtaining soil texture or named stream network data or creating treatment or vegetation type data, please refer to **Appendix A** before proceeding.

Implementation of Disturbed WEPP Treatment Area Processing

1. Open the **Disturbed WEPP Treatment Area Processing** tool by clicking on **Step 3A: Disturbed WEPP Treatment Area Processing** in the Hillslope Delineation Toolbox. If yellow exclamation points occur next to any of the outputs, don't be concerned. This indicates that the file that you are trying to generate already exists. Once you choose a new file name, the exclamation point errors will disappear.

*** Step 3A: Disturbed WEPP Treatment Area Processing	
Input Hillslope Polygons Input Treatment or Vegetation Type Polygons Input Named Stream Network Polylines	Processing Step3A is for users who intend to model hillslopes using Disturbed WEPP. This tool intersects the hillslope
OK Cancel Environments) << His	Hide Help Tool Help

2. Click on the file folder icon next to the **Input Hillslope Polygons** drop-down menu and navigate to the hillslope polygon input shapefile that you created in Step 2. Don't be concerned if you see an error warning at this point.

jr 10-04818-000 hillslope toolbox user guide - arcgis 10

- 3. Click on the file folder icon next to the **Input Treatment or Vegetation Type Polygons** drop-down and navigate to the treatment or vegetation type data that you want to intersect with the hillslopes.
- 4. Click on the file folder icon next to the **Input Named Stream Network Polylines** drop-down menu and navigate to the stream network shapefile that you would like to use for determining the names of streams adjacent to hillslopes.

If you don't have a stream network shapefile with names available, select the stream network shapefile you generated in Step 2. This will allow the tool to function properly, but will not return any stream name values.

- 5. Click on the file folder icon next to the **Input Soil Texture Polygons** and navigate to the soil texture shapefile that you want to intersect with the hillslopes.
- 6. Click in the **Output Disturbed WEPP Hillslope Polygons** box to name your output file. A suggested naming convention for this file is "disturbed_wepp_hillslope_polygons_step3A.shp".
- 7. Click OK.

Step 3B1: ERMiT Treatment Area Processing

The next tool in the Hillslope Delineation Toolbox is **ERMiT Treatment Area Processing**. If you would like to generate data for the Disturbed WEPP batch model instead, please skip to **Step 3A: Disturbed WEPP Treatment Area Processing.** The purpose of this tool is to intersect the hillslope polygons created in Step 2 with vegetation type and soil texture polygons data to generate hillslope input for the ERMiT batch model. Optionally this tool also allows you to input named stream network polylines to determine which streams are adjacent to hillslopes. The following output files will be generated by this tool:

ERMiT Hillslope Polygons

The **Treatment Area Processing** tool has only one output file. This file is an intersection of hillslopes, vegetation type, and soil texture data. It is possible for there to be more than one hillslope in a vegetation type area. Each intersection in the output file is a hillslope polygon with a unique ID. If you choose to enter named stream network data, the name of the adjacent stream for each polygon will be included in the output file. Not all hillslopes have an adjacent stream.

If you need help in obtaining soil texture or named stream network data or creating vegetation type data please refer to **Appendix A** before proceeding.

Implementation of ERMiT Treatment Area Processing

1. Open the **ERMiT Treatment Area Processing** tool by clicking on **Step 3B1: ERMiT Treatment Area Processing** in the Hillslope Delineation Toolbox. If yellow exclamation points occur next to any of the outputs, don't be concerned. This indicates that the file that you are trying to generate already exists. Once you choose a new file name, the exclamation point errors will disappear.

 Input Hillslope Polygons Input Hillslope Polygons Input Vegetation Type Polygons Input Named Stream Polylines Input Soli Texture Polygons Output ERMIT Hillslope Polygons D:\Temp\ermit_hillslope_polygons_step38.shp 	0
Input Vegetation Type Polygons Input Named Stream Polylines Input Soil Texture Polygons Output ERMIT Hillslope Polygons	
Input Soil Texture Polygons	
Output ERMIT Hillslope Polygons	
	_
OK Cancel Environments << Hide Help Tool Help	M

- Click on the file folder icon next to the Input Hillslope Polygons drop-down 2. menu and navigate to the hillslope polygon input shapefile that you created in Step 2. Don't be concerned if you see an error warning at this point.
- 3. Click on the file folder icon next to the Input Vegetation Type Polygons dropdown and navigate to the vegetation type data that you want to intersect with the hillslopes.
- 4. Click on the file folder icon next to the Input Named Stream Network Polylines drop-down menu and navigate to the stream network shapefile that you would like to use for determining the names of streams adjacent to hillslopes.

If you don't have a stream network shapefile with names available, select the stream network shapefile you generated in Step 2. This will allow the tool to function properly, but will not return any stream name values.

- 5. Click on the file folder icon next to the Input Soil Texture Polygons and navigate to the soil texture shapefile that you want to intersect with the hillslopes.
- 6. Click in the **Output ERMiT Hillslope Polygons** box to name your output file. A suggested naming convention for this file is "ermit hillslope polygons step3B1.shp".
- 7. Click OK.

Step 3B2: ERMIT Burn Severity Processing

The next tool in the Hillslope Delineation Toolbox is **ERMIT Burn Severity Processing.** This step is intended for users who are preparing input data for the ERMIT model only.

The purpose of this tool is to calculate an average burn severity value for each hillslope based on a user-provided burn severity raster. Input data must be in a raster format for this tool to function properly. The following output file will be generated by this tool:

Burn Severity Table

The **ERMIT Burn Severity Processing** tool has only one output file, which is a table of burn severity values that is automatically joined to the output polygon file generated in Step 3B1.

Implementation of ERMIT Burn Severity Processing

 Open the ERMIT Burn Severity Processing tool by clicking on Step 3B1: ERMIT Burn Severity Processing in the Hillslope Delineation Toolbox.

** Step 3B2: ERMIT Burn Severity Processing	
Input ERMIT Hillslope Polygons Input Burn Severity Grid Input Burn Severity Grid Input ERMIT Hillslope Zone Field Input ERMIT HILL INPUT ERMI	Step 3B2: ERMIT Burn Severity Processing This tool allows ERMiT users to calculate average burn severity for each hillslope generated in Step 3B1.
OK Cancel Environments) << Hide Help	Tool Help

- 2. Click on the file folder icon next to the **Input ERMiT Hillslope Polygons** drop-down menu and navigate to the ERMiT hillslope polygons that you created in Step 3B1.
- 3. Click on the file folder icon next to the **Input Burn Severity Grid** drop-down meanu and navigate to the location of your burn severity raster dataset.
- 4. Under the **Input ERMiT Hillslope Zone Field** drop-down, select **NEWID**.
- 5. Click **OK**.

Burn severity statistics have now been joined to the hillslope output polygons from Step 3B1.

Step 4: Representative Slope Profile Extraction

The next tool is **Representative Slope Profile Extraction**. The purpose of this tool is to extract percent slope and flow length from every cell along every possible flow path in each hillslope. This information will be processed in Steps 5 and 6 to extract a linear average representative slope profile for each hillslope for use in the Disturbed WEPP or ERMiT batch models. Step 5 will provide more detail about the algorithm used to extract the slope profile. The following output file will be generated by this tool:

Flowpath Points Output

The **Representative Slope Profile Extraction** tool has only one output file, which is a point file of the centerpoint of each pixel in each flow path by hillslope. Each point has an ID number associating it with a hillslope, a length value indicating how far upstream the point is from the channel it drains to and a percent slope value at that point. A hillslope may have many different possible flow paths.

Implementation of Representative Slope Profile Extraction

 Open the Representative Slope Profile Extraction tool by clicking on Step 4: Representative Slope Profile Extraction in the Hillslope Delineation Toolbox. If yellow exclamation points occur next to any of the outputs, don't be concerned. This indicates that the file that you are trying to generate already exists. Once you choose a new file name, the exclamation point errors will disappear.


Step 4: Representative Slope Profile Extraction	
	Step 4: Representative Slope Profile Extraction
Raster cell size O Linear unit Meters	This tool extracts a representative slope profile for
) Field	each hillslope generated in Steps 3A or 3B based on all possible flowpaths. For more
Input Hillslope Treatment Polygons Input Flow Accumulation Grid	detailed information on the methodology used for this step, please see the Toolbox User
Input Flow Direction Grid	Guide document.
Input Clipped Elevation Grid	8
Output Flowpath Points	
D:\Temp\representative_flowpath_pts_step4.shp	
OK Cancel Environments << Hide	Help Tool Help


jr 10-04818-000 hillslope toolbox user guide - arcgis 10

- 2. Click on the file folder next to the **Input Stream Network Polylines** drop-down and navigate to the grid stream network you created in Step 2.
- 3. The next box is for **Raster cell size**. Type in the resolution of your elevation raster into this box. If you have been working with a 10-meter DEM for example, you would type in the value 10 in the Linear unit box.
- 4. Click on the file folder icon next to the **Input Hillslope Treatment Polygons** drop-down menu and navigate to the hillslope treatment polygons shapefile that you created in Steps 3A or 3B1, depending if you want to generate an input file for the Disturbed WEPP or ERMiT batch models..
- 5. Click on the **Input Flow Accumulation Grid** drop-down menu and select the flow accumulation grid that you created in Step 1.
- 6. Click on the **Input Flow Direction Grid** drop-down menu and select the flow direction grid that you created in Step 1.
- 7. Click on the **Input Clipped Elevation Grid** drop down and select the elevation grid that you created in Step 1.
- 8. Click in the **Output Flowpath Point** box to name your output file. A suggested naming convention for this file is "representative_flowpath_pts_step4.shp".
- 9. Click **OK**.

The two images below represent the flowpath point output. The first has a color gradient representing distance from the channel (FLENG column). Dark blue points are closest to the channel and bright red points are furthest away. The second represents percent slope (SLP column). Dark blue points have low slopes and red points are steep. This data will be processed into a usable form for the Disturbed WEPP or ERMiT batch models in the next step.

(1)





Step 5: Process Representative Slope Profile

The next tool in the Hillslope Delineation Toolbox is **Process Representative Slope Profile.** The purpose of this tool is to process the representative slope profile data created in the previous steps into a format that will be processed in the next step into one comprehensive output file for the Disturbed WEPP or ERMIT batch models. The **Process Representative Slope Profile** tool has many steps that are run in the background and will take more time than the other steps to run. Please be patient while this step is running. It may take several minutes to fully complete.

The following output file will be generated by this tool:

Temporary Hillslope Table

(2)

The **Process Representative Slope Profile** tool has only one output file. This is a table of the hillslope and representative slope profile data that will be processed in Step 6 into a CSV file that can be imported into the Disturbed WEPP and ERMIT batch models. Each row in the output file is an individual hillslope with a unique identifier field named HS_ID.

The Hillslope Delineation Toolbox uses a linear averaging algorithm (Cochrane and Flanagan 2003) to extract a representative slope profile from all possible flowpaths in each hillslope. This method assumes that all flowpaths regardless of length have an equal impact on soil loss. For more detailed information on this approach, please see the Cochrane and Flanagan paper at: http://agteca.org/publications/asae46(4)1041-1049.pdf.

Implementation of Process Representative Slope Profile

1. Open the **Process Representative Slope Profile** tool by clicking on **Step 5: Process Representative Slope Profile** in the Hillslope Delineation Toolbox. If yellow exclamation points occur next to any of the outputs, don't be concerned. This indicates that the file that you are trying to generate already exists. Once you choose a new file name, the exclamation point errors will disappear.

** Step 5: Process Representative Slope Profile	
Input Flowpath Points Input Flowpath Points Output Temporary Hillslope Table Dr(Temp(temporary_hillslope_table_step5	Input Flowpath Points
OK Cancel Environments) << Hide Help	Tool Help

- 2. Click on the file folder icon next to the **Input Flowpath Points** drop-down menu and navigate to the representative slope point file that you created in Step 4.
- 3. Click on the folder icon next to the **Output Temporary Hillslope Table** box and navigate to the location where you would like to save your output table.
- 4. Click **OK**.

Step 6: Export Hillslope Data

The final tool in the Hillslope Delineation Toolbox is **Export Hillslope Data**. The purpose of this tool is to take the output table created in Step 5 and combine it with user input to create one output file formatted in a way that can be easily upload into the Disturbed WEPP and ERMIT batch models. The following output file will be generated by this tool:

Formatted Hillslope Output Table

The **Export Hillslope Data** tool has only one output file. This is a table of the combined hillslope and representative slope profile data that will be processed at the end of this step into a commadelimited text file for input into the Disturbed WEPP and ERMIT batch models. Each row in the output file is an individual hillslope with a unique identifier field named HS_ID. Table 1 below shows a complete list of the fields and field types that are included in the output file.

Field Description	Field Name	Field Type
Hillslope Unique ID	HS_ID	Long
Unit ID Number	UNIT_ID	Text
Land Type Code	LAND_TYPE	Text
Area (Acres)	AREA	Double
Upper Treatment Area Type	UTREAT	Text
Upper Hillslope Slope Profile Length	USLP_LNG	Double
Upper Hillslope Top Slope (Percent)	UGRD_TP	Double
Upper Hillslope Bottom Slope (Percent)	UGRD_BTM	Double
Lower Treatment Area Type	LTREAT	Text
Lower Hillslope Slope Profile Length	LSLP_LNG	Double
Lower Hillslope Top Slope (Percent)	LGRD_TP	Double
Lower Hillslope Bottom Slope (Percent)	LGRD_BTM	Double
Adjacent Stream Name	ADJ_STRM	Text
Stream Tributary	TRIB_TO	Text
ERMIT Top Slope (Percent)	ERM_TSLP	Double
ERMIT Middle Slope (Percent)	EM_MSLP	Double
ERMIT Bottom Slope (Percent)	ERM_BSLP	Double
ERMIT Burn Severity	BURNSEV	Double

 Table 1.
 Formatted hillslope output table fields.

Implementation of Export Hillslope Data

1. Open the **Export Hillslope Data** tool by clicking on **Step 6: Export Hillslope Data** in the Hillslope Delineation Toolbox. If yellow exclamation points occur next to any of the outputs, don't be concerned. This indicates that the file that you are trying to generate already exists. Once you choose a new file name, the exclamation point errors will disappear.

nput Table	<u>^</u>	Step 6: Export Hillslope		
	I 🔁	Data		
nput Treatment Unit ID Field		Shade Server 1		
[UNIT_ID]		This tool converts the		
nput Soil Texture Field		representative flowpath table		
[SOIL_TYPE]		created in Step 5 into an output file that is compatible with the		
nput Upper Treatment or Vegetation Type Field		Disturbed WEPP and ERMIT		
[UTREAT]		batch model spreadsheets.		
nput Lower Treatment or Vegetation Type Field				
[LTREAT]				
nput Adjacent Stream Name Field				
[ADJ_STRM]				
nput Stream Tributary Field				
[TRIB_TO]				
elete Fields				
Select All Unselect All	Add Field			

- 2. Click on the **Input Table** dropdown and select the formatted hillslope output table you generated in Step 6.
- 3. Click in the **Input Treatment Unit ID Field** box. The next several input boxes require some background explanation.

Because the Disturbed WEPP and ERMIT batch models require input files with certain field names only and in a certain order, it is necessary to rename the fields from the data you have entered into the Toolbox to match this format. For example, if your input treatment area data had a field named Poly_UID to represent Unit ID, this will have to be converted to match the UNIT_ID field format required by the Disturbed WEPP and ERMIT batch models. For more detailed instructions on determining these field names, please refer to **Appendix A.**

In the **Input Treatment Unit ID Field** box, type in the name of the field in your output table from Step 5 that that represents the Unit ID. The field name must be typed in brackets. In the example above, you would type **[POLY_UID]**.

Important: You MUST enter a field name in each box.

If you don't have a corresponding field name that you want to transfer from your input table, please leave the default field names provided.

4. Click in the **Input Soil Texture Field** box and type in the name of the field in brackets in output table from Step 5 that represents the hillslope soil texture.

- 5. Click in the **Input Upper Treatment or Vegetation Type Field** box and type in the name of the field in brackets in your output table from Step 5 that represents the upper hillslope treatment type.
- 6. Click in the **Input Lower Treatment or Vegetation Type Field** box and type in the name of the field in brackets in your output table from Step 5 that represents the lower hillslope treatment type. **Note:** ERMiT does not have upper and lower treatment types. If you are generating output for the ERMiT batch model, enter your vegetation type field in brackets for both the **Input Upper Treatment or Vegetation Type Field** box and the **Input Lower Treatment or Vegetation Type Field** box.
- 7. Click in the **Input Adjacent Stream Name Field** box and type in the name of the field in brackets in your output table from Step 5 that represents the names of adjacent streams.
- 8. Click in the **Input Stream Tributary Field** box and type in the name of the field in brackets in your output table from Step 5 that represents the names of tributaries to adjacent streams.

The figure below shows field names entered for all boxes. In this example, there is no field information to transfer for stream tributary information, so the default field name from Table 1 is entered into the **Stream Tributary Field** box.

🍽 Step 6: Export Hillslope Data		
Input Table		2
temporary_hillslope_table_step5		- 🖻
Input Treatment Unit ID Field		
[unit_id_1]		
Input Soil Texture Field		
[map_unit]		
Input Upper Treatment or Vegetation Type Field		
[vtype]		
Input Lower Treatment or Vegetation Type Field		
[vtype]		
Input Adjacent Stream Name Field		
[ADJ_STRM]		
Input Stream Tributary Field		
[TRIB_TO]		
 Delete Fields 		
		<u>^</u>
		~
<		>
Select All Unselect All		Add Field
Formatted Hillslope Output Table		
D:\Temp\batch_model_hillslope_output		E
		×
	OK Cancel Environments	. Show Help >>
-		

9. Notice that there is a list of fields with check boxes in the **Delete Fields** box. This is a complete list of all fields that are in the output file that you generated in Step 5. To ensure that the final output file is compatible with the Disturbed WEPP or ERMIT batch models, it is necessary to delete any additional fields that are not included in Table 1.

Click on the **Select All** button under the **Delete Fields** box. Starting at the top, look for the field **HS_ID** and uncheck the box. Then uncheck each box after it until you reach **BURNSEV**. Everything after this field should remain checked. This represents all of the fields shown in Table 1 and will delete all other fields that are not in the proper format for the Disturbed WEPP and ERMIT batch models.

Step 6: Export Hillslope Data		
Input Table		
temporary_hillslope_table_step5		🗾 🖻
Input Treatment Unit ID Field		
[unit_id_1]		
Input Soil Texture Field		
[map_unit]		
Input Upper Treatment or Vegetation Type F	ield	
[vtype]	1.00	
Input Lower Treatment or Vegetation Type F	ield	
[vtype]		
Input Adjacent Stream Name Field		
[ADJ_STRM]		
Input Stream Tributary Field		
[TRIB_TO]		
Delete Fields		
SOIL_TYPE		
USLP_LNG UGRD_TP		
		×
<		>
Select All Unselect All		Add Field
	OK Cancel	Environments Show Help >>

- 10. Click on the **folder icon** next to the **Formatted Hillslope Output Table** box and navigate to the location where you would like to save your output table.
- 11. Click **OK.**

Step 7: Export Hillslope CSV File

IMPORTANT: One step outside of the Toolbox is necessary to convert the DBF file created in Step 6 to a comma-delimited CSV that will be compatible with the Disturbed WEPP and ERMiT batch models.

28

- 1. Click the Source tab and right-click on the output table in the ArcMap Table of Contents and click Export.
- 2. Click on the file folder in the Output table: box and navigate to the location where you want to save your data.
- 3. Click on the Save as type drop-down box and select Text File.

Saving Data					
Look in: 📔] Test		• •	. 380	
Name		Туре			
1	-				-
Name:	Export_Output.txt				Save
Save as type:	Text File			•	Cancel
1					

4. Click in the **Name:** box and change the file extension to **.CSV.** This will save your file in a comma-delimited format that is ready to be imported into the Disturbed WEPP and ERMIT batch models. Feel free to name the file whatever you would like.

Formatted Hillslope Output Table					
Look in: 🧰	Test		- 6		
Name		Туре			
Export_Ou	tput.csv	Text File			
Name:	Export_Output.csv				Save
Save as type:	Tables			•	Cancel

jr 10-04818-000 hillslope toolbox user guide - arcgis 10

- 5. Click Save.
- 6. Click **OK.**

Your data is now formatted and ready to be imported into the Disturbed WEPP and ERMIT model batch macro spreadsheets.

APPENDIX A

Toolbox User Resources

Data Gathering

The Hillslope Delineation Toolbox requires you to obtain or create a few GIS datasets to generate output for the Disturbed WEPP or ERMiT batch models. The following sections provide some basic information on obtaining and creating GIS data for the Hillslope Delineation Toolbox.

Data Gathering

The Hillslope Delineation Toolbox requires a few GIS datasets to run successfully. These include an elevation raster such as a 10-meter DEM or LiDAR, polygons describing treatment or vegetation types, soil type polygons and optionally stream centerline data with names. Some of this data is publicly available, such as elevation data, soil types, and stream centerlines. Other data like treatment area or vegetation types are generated by the user. Below is some information on public data sources to help you with data gathering Basic information on creating new GIS data can be found in the next section.

Elevation Grid

Elevation gridscan be obtained for most areas from USGS with 10-meter pixels. For more information, please see the USGS website at <u>http://eros.usgs.gov/#/Guides/dem</u>. Higher resolution data like LiDAR may be available on a project basis depending on the geographic extent. For example, Washington State has a public LiDAR Consortium website with data for a portion of the state and Oregon has a similar site being produced. A quick look at a search engine will help you determine what is available for your specific area.

Stream Centerlines

Stream data is readily available for most areas in a range of resolutions and with many different attributes. One good source of stream data for the continental United States is the National Hydrography Dataset from USGS. The website address is <u>http://nhd.usgs.gov/data.html</u>. Websites like the University of Oregon Library site also often have lists of GIS data sources that are available by state. This site is located at <u>http://libweb.uoregon.edu/map/map_section/map_Statedatasets.html</u>.

Soil Types

Soil data is available for download for most areas through the USDA National Resources Conservation Service website. This site is located at <u>http://soildatamart.nrcs.usda.gov/SDM%20Web%20Application/default.aspx</u>.

Data Creation

Some datasets required for the Hillslope Delineation Toolbox such as vegetation and treatment types may not be readily available from a public source and will instead need to be generated by

jr 10-04818-000 hillslope toolbox user guide arcgis 10 - appendix a

the user before running the Toolbox. If you are unfamiliar with GIS and need further assistance on generating your own data, please refer to the following ArcGIS 10 tutorial sources:

- http://help.arcgis.com/en/arcgisdesktop/10.0/help/index.html#/ArcGIS_tutorials/0 0v20000000t000000/
- http://blogs.esri.com/esri/esritrainingmatters/2009/08/11/need-gis-data-learn-howto-create-your-own/

Data Preprocessing

Data inputs for the Hillslope Delineation Toolbox meet a couple of basic requirements before they can be used successfully. First, all data needs to be in one common coordinate system. Second, the elevation dataset used needs to be one single raster grid. The following sections provide some basic information on preprocessing data if you have multiple elevation grids or multiple coordinate systems.

Preparing the Elevation Grid

The Hillslope Delineation Toolbox can only process one elevation grid at a time. If you have more than one elevation grid for your project area, you will need to merge them into one large elevation grid before you begin. The following steps describe how to do this.

These instructions assume that your rasters are already in one common coordinate system. If they are not, please see the *Converting to a Common Coordinate System* section of this user guide before proceeding. This also assumes that you are working with rasters with the same pixel size. Detailed information on resampling pixel size is not provided in this user guide.

1. Open ArcToolbox, click on Data Management Tools, and navigate to the Mosaic to New Raster tool.

analysis Tools	Mosaic To New Raster	
Cartography Tools Conversion Tools		
🚳 Data Interoperability Tools	Input Rasters	input reasters
🚳 Data Management Tools		
🕀 🚳 Data Comparison		The input raster
🕀 🚳 Database		+ datasets.
🗉 🚳 Disconnected Editing		
🕀 🚳 Distributed Geodatabase		×
🖅 🥸 Domains		
🕀 🚳 Feature Class		1
🖅 🚳 Features		
🕀 🥸 Fields		Ŧ
🖅 💩 File Geodatabase		
🖅 💩 General		
🕀 🥸 Generalization		
🕀 🥸 Indexes	Output Location	and the second sec
🕀 🥸 Joins		i i i i i i i i i i i i i i i i i i i
🗉 🚳 Layers and Table Views	Raster dataset name with extension	
🗄 🚳 Projections and Transformations		
🖻 🔕 Raster	Coordinate system for the raster (optional)	
😟 🏷 Raster Catalog		6
🖃 🏷 Raster Dataset		
Copy Raster	Pixel type (optional)	
🖉 🔑 Create Random Raster	8_BIT_UNSIGNED	<u> </u>
Create Raster Dataset	Cellsize (optional)	
Mosaic		
	Number of bands	
Raster Catalog To Raste		1
Workspace To Raster D	Mosaic Method (optional)	
🕀 💩 Raster Processing		
🗄 💩 Raster Properties	OK Cancel Environments << Hi	lide Help Tool Help
🕀 💩 Relationship Classes		
🕀 💩 Subtypes		
🕀 💩 Table		
🗄 💩 Topology		
🛨 🍆 Versions		
Ŧ 💩 Workspace		
Seocoding Tools		
Geostatistical Analyst Tools		
💑 Hillslope Delineation Tools		
A Linear Deferencing Tools		

jr 10-04818-000 hillslope toolbox user guide arcgis 10 - appendix a

- 2. Click on the file folder next to the **Input Rasters** box and navigate to the location where your elevation grids are saved. Repeat this step until you've added all of your individual elevation grids to the input box.
- 3. Click on the file folder next to the **Output Location** box and navigate to the location where you want to save your merged elevation grid.
- 4. Click in the **Raster dataset name with extension** box and type in a name for your output merged elevation raster. A suggested naming convention for this output file is "mrg_elev".
- 5. Leave the **Coordinate system for the raster** box blank. You should have already converted all of your grids to a common coordinate system before this step, so the default coordinate system is fine.
- 6. Click on the **Pixel type** drop-down menu. Change this value to **32_BIT_FLOAT**.
- 7. Click in the **Cellsize** box and type in the same pixel resolution as your input rasters.
- 8. Click **OK**.

Converting to a Common Coordinate System

Datasets with different coordinate systems should not be used in the Hillslope Delineation Toolbox. Although the toolbox may appear to function correctly, differences in coordinate systems can introduce error into your analysis that may be difficult to identify in the results. The following steps will help make sure that you have no coordinate system problems with the toolbox.

- 1. Add all of the datasets that you plan to use in your analysis into an ArcMap project. This includes your elevation grid, treatment area data, landuse data, and named streams.
- 2. Right click on your **elevation grid data**, click **Properties**, and then click the **Source** tab. This brings up the **raster properties** window. Scroll down until you see the **Spatial Reference** information. This tells you what coordinate system your elevation grid is in.

roperty	Value	~
Spatial Reference	NAD_1983_UTM_Zone_12N	
Linear Unit	Meter (1.000000)	
Angular Unit	Degree (0.017453292519943295)	
False_Easting	500000	
False_Northing	0	
Central_Meridian	-111	
Scale_Factor	0.9996	
Latitude_Of_Origin	0	
Datum	D_North_American_1983	~
ata Source		
Folder: C:\`	System Raster Femp\HS\ 110m <u>S</u> et Data Sour	·ce

- 3. Repeat this step for each dataset that you plan to use in your analysis. If all of the coordinate systems for each dataset are the same you are done. If not, the next step is to project your datasets into one common coordinate system.
- 4. The coordinate system of your merged elevation grid is what will determine the coordinate system for the rest of your data. If you are working with multiple elevation grids with different coordinate systems that need to be merged together, you will first need to project these datasets into one common coordinate system.

Open ArcToolbox, click on Data Management Tools, and navigate to the **Project Raster** tool.

jr 10-04818-000 hillslope toolbox user guide arcgis 10 - appendix a

	Summer of the second	
ArcToolbox		
arcioolbox 🔗 🐴 3D Analyst Tools		
Analysis Tools		
Cartography Tools		
Conversion Tools		
Data Interoperability Tools		
Data Management Tools	🎤 Project Raster	
🕀 🕎 Data Comparison	×	
🕀 🥸 Database	Input Raster	Project Raster
🕀 🥸 Disconnected Editing		
🕀 🥸 Distributed Geodatabase	Input Coordinate System (optional)	Transforms the raster
🕀 🥸 Domains		dataset from one
🗄 🥸 Feature Class		projection to another.
🗄 🥸 Features	output Raster Dataset	1. 3
主 💩 Fields 👘 👘		
🗄 💩 File Geodatabase	Output Coordinate System	
🗄 💩 General		
🗄 🍝 Generalization		
🕀 🍝 Indexes	Geographic Transformation (optional)	
🗄 💩 Joins		
🗄 💩 Layers and Table Views		
Projections and Transformations		
E S Raster	×	
Mirror	÷	
Project Raster		
	1	
Rescale		
- A Rotate		
A Warp	Resampling Techingue (optional)	
Create Custom Geographic 1	NEAREST	
	Output Cell Size (optional)	
🖻 🥸 Raster		
🗄 🥸 Raster Catalog		4
🖃 🥸 Raster Dataset		
n Copy Raster	OK Cancel Environments << Hide Help	Tool Help
Create Raster Dataset		
Mosaic		
Mosaic To New Raster		
🔪 Raster Catalog To Raste		
->> Workspace To Raster De		
🗖 🎰 Discher Drocession 🛛 🎽		
Dector Droceccion	and the second se	

The coordinate system for the majority of your elevation grids is the coordinate system you should project your other grids to. For example, if you have four elevation grids and three are in the same coordinate system, that is the coordinate system you should use for your analysis.

- 5. Click on the file folder next to the **Input Raster** box and navigate to the raster that you need to project.
- 6. Click in the **Output Raster Dataset** box and type in a name for your projected raster. Remember that the limit for raster naming is 13 characters.
- 7. Click on the icon next to the **Output Coordinate System** box and click on **Import**.

Spatial Referen	ce Properties	? 🔀
XY Coordinate Sys	tem Z Coordinate System	
Name: Ui	nknown	
, Details:		
		~
		<u>M</u>
Select	Select a predefined coordinate system.	
Import	Import a coordinate system and X/Y, Z and M domains from an existing geodataset (e.g., feature dataset, feature class, raster).	
<u>N</u> ew +	Create a new coordinate system.	
Modify	Edit the properties of the currently selected coordinate system.	
⊆lear	Sets the coordinate system to Unknown.	
Sa <u>y</u> e As	Save the coordinate system to a file.	
-	OK Cancel	Apply

- 8. Navigate to the location of one of your raster datasets with the coordinate system you want to use for your project. Click **OK**. Repeat the **Project Raster** step as necessary until all of your raster datasets are in one common coordinate system. See the *Preparing the Elevation Grid* section of this user guide for instructions on how to combine these grids into one elevation raster.
- 9. Now you will repeat the projection steps describe above for your other datasets. These are polygon or polyline files, so the **Project** tool for features is used.

Open ArcToolbox, click on Data Management Tools, and navigate to the **Project** tool under Feature.

	The second se	
i x		
ArcToolbox		
🗄 🊳 3D Analyst Tools		
🗄 🍓 Analysis Tools		
Cartography Tools		
🗄 🥘 Conversion Tools		
🗄 🍑 Data Interoperability Tools	Carlos anton	
🖻 🍑 Data Management Tools	noject	
🕀 🥸 Data Comparison		
🕀 🥸 Database	🖕 Input Dataset or Feature Class	Project
🕀 🥸 Disconnected Editing		
🕀 🌜 Distributed Geodatabase	Input Coordinate System (optional)	Changes the coordinate
🕀 🍆 Domains		system of your Input
🕀 🌜 Feature Class		Dataset or Feature
🕀 🌜 Features	💊 Output Dataset or Feature Class	Class to a new Output
🕀 💩 Fields		Dataset or Feature
🕀 🍝 File Geodatabase	Output Coordinate System	Class with the newly
🛨 🍝 General		defined coordinate
Ŧ 💩 Generalization		system, including the
🖅 🏡 Indexes	Geographic Transformation (optional)	datum and spheroid.
🕀 🧑 Joins		datum and spheroid.
🕀 💩 Layers and Table Views		
E S Projections and Transformations	+	
E S Feature		INPUT
Batch Project	X X	19
Accent roject		162-
Project		A CONTRACT
+ 🗞 Raster		Cand Mary MCG
Create Custom Geographic 1	+	~ ~
Define Projection		GC5_GR5_1980 Scale: 1:16,500,00
+ 🗞 Raster		·
Kaster Kaster Kaster Kaster Kaster		+
Subtypes		OUTPUT
		OBIFUI
		13.
Versions		1 tan m
Workspace	<u></u>	1 T3 M
Geocoding Tools	OK Cancel Environments << Hide Help	Tool Help
	OK Cancel Environments << Hide Help	
🕀 🍓 Geostatistical Analyst Tools		
Hillslope Delineation Tools		
Constant Referencing Tools	- same	
🗄 🥎 Mobile Tools		
Multidimension Tools		
Network Analyst Tools Samples		
< N		
Favorites Index Search Results	0 D C II 4	

- 10. Click on the file folder next to the **Input Dataset or Feature Class** box and navigate to the shapefile that you need to project.
- 11. Click in the **Output Dataset or Feature Class** box and type in a name for your projected shapefile.
- 12. Click on the icon next to the **Output Coordinate System** box and click on **Import**.

Spatial Reference	e Properties	?×
XY Coordinate Sys	tem Z Coordinate System	
Name: Un	known	_1
, include the second se	NIOWI	- 1
Details:		~
		-
Select	Select a predefined coordinate system.	
	Import a coordinate system and X/Y, Z and M	
Import	domains from an existing geodataset (e.g., feature dataset, feature class, raster).	
<u>N</u> ew +	Create a new coordinate system.	
M <u>o</u> dify	Edit the properties of the currently selected coordinate system.	
⊈ear	Sets the coordinate system to Unknown.	
Save As	Save the coordinate system to a	
	file.	
	OK Cancel A	pply
		PPIY

13. Navigate to the location of one of your elevation grid and then click **OK**. Repeat the **Project** step as necessary until all of your feature datasets are in one common coordinate system.

Additional Toolbox Assistance

This section provides a more detailed description of how to run the Hillslope Delineation Toolbox to help the casual GIS user.

Running "Step 6: Export Hillslope Data"

The purpose of the final step in the Hillslope Delineation Toolbox is to format the output table created in the first five steps of the toolbox so that it can be easily upload into the Disturbed WEPP or ERMIT batch models. For each field that will be included in the final model output, you will need to specifically tell the model what field in your output data points to it.

Say that you want to find out what column name from your model output table should be entered in the **Input Treatment Unit ID Field** below.

Step 6: Export Hillslope Data	
• Input Table	Step 6: Export Hillslope
Input Treatment Unit ID Field	Dum
	This tool converts the
Input Soil Texture Field	representative flowpath table
[SOIL_TYPE]	created in Step 5 into an output file that is compatible with the
Input Upper Treatment or Vegetation Type Field	Disturbed WEPP and ERMIT
[UTREAT]	batch model spreadsheets.
Input Lower Treatment or Vegetation Type Field	8
[LTREAT]	
Input Adjacent Stream Name Field	
[ADJ_STRM]	
Input Stream Tributary Field	
[TRIB_TO]	
Delete Fields	
Select All Unselect All Add Field 💽	
OK Cancel Environments) << Hide Help	Tool Help

To do this, you will first click on the **List by Source** icon in the Table of Contents and then right click on your output table to view the column information.

			🖑 🥝 💥 🖓 🖛 🔿	▼ Layer: dem.tif		Q • 💒 🖬 📮	
) 🔁 🖨 🕼 🐇 🗿 🛍 🗙 🖙 🔿 🔶 -	1:36,016	🔽 🔜 🗔 🥫 🖾 🕻	∞ k? ₌				
<mark>rGW</mark> Help ▼ _∓							
oology:	KK KP KL KK Ⅲ H		🛛 Drawing 🕶 💺 🛞 🔠 🗌	- A - 🖂 🚺	Arial	✓ 10 ✓ B I	U A - 3 .
Editor	$ Z \in A^* \oplus D$	中中大の国図園。					
	× Table						
0 😔 📮 街 🗄	📃 • 🔤 • 🔚 💀	2 🖗 🗙					
Jayers	temporary_hillslope_tab	e step5					
Contemporary States (10-04818-000) Shape (From_SueM	PL CONTRACTOR CONTRACTOR	SOIL TYPE AREA UTREAT	USLP LNG UGRD TP	UGRD BTM LTREA	T LSLP LNG LGRD		J STRM TRIB T
🗄 🗌 dem.tif	12	0	0 0		0	0 2	
🔳 🔲 burn_severity.img	15	0	5 9.5	9.5	5 6	75 6.75	1
K:\Projects\10-04818-000\Output	18	0	10 12	22	10	22 .15	
temporary_hillslope_table_step5	20	0	0 0		0	0 .17	
	21	0	5 12.142857		5 15.3333		
	22	0	0 0	0	0 5 20.3333	0 12.833333 33 20.3333333	
	23	0	15 19.5		15 27.5555		
	24	0	10 17.666667	21.727273		21 16.75	
	27	0	20 23.5	23		20 20.083333	
	29	0	10 26.833333	28.583333	10 28.5833		
	32	0	5 16.75		5 19.5555		
	33	0	0 0	0.5	0	0 0	
	34	0	0 0		0	0 6.333333	
	35	0	35 4.875 45 15.666667	18.518182 19.588889	35 13.8472		
	39	0	35 10.875	10.936364	35 20.3070		
	40	0	30 36.055556	32.666667	30 30.8072		
	41	0	35 29.847619	41.597222		2.5 22	1
	42	0	45 15.458333	27.393939	45 19.0769	23 22.136364	
	43	0	0 8.5	The second se	0	0 0	1
	44	0	30 29		30 28.3393		
	45	0	25 30.50962	32.421053 0	25 28.4545	45 16.333333 0 .16	
	40	0	45 16.027778		45 22.0673		
	48	0	45 10.02/170		45 20.2152		1
	49	0	40 14.6		40 21.4583		
	50	0	20 6	2	2010	1.8 16.357143	
	53	0	45 18.148148			25 21.866667	
	54	0	40 7	26.5625	40 29.6		
	55	0	15 8 45 6.152778		15 22.3333		
	57	0	45 6.152776	Accession/2012/2012/2012	45 19	0 7.2	
	58	0	30 27.339286		30 20.8714		
	59	0	40 18.75	17.641667		1.5 13.558741	
	60	0	50 6.224747	6.642857	50 5.9563		
	63	0	45 9.055556	17.190476	45 20.8958		
	64	0	15 9	26.333333		1.6 14.333333	
	<						
	14 4 0	▶ ▶1 🔲 💷 (0 out of 170 Sele					

Notice that the first 18 columns (up through **BURNSEV**) match the columns listed in Table 1 in the main user guide. These are the "placeholder" columns that have been set up to ensure compatability with the Disturbed WEPP or ERMiT batch models. Scroll to the right past the **BURNSEV** field. These are the field names that will be entered into Step 6 of the Toolbox. Don't be concerned if your field names differ from this example.

					🖑 🥥 👯 🖸	eferencing + Lav					1 🖬 🖕	
	.00.01C						dom.u					
) 🔁 🖬 🖨 % 🗿 🖺 🗙 🔊 🗠 🔶 - 🛽	36,016	V	· 📈 🖂 🇊									
<mark>'GW</mark> Help ▼ _∓												
pology: 🚽 😪 🔂 🔣		日山			Drawing - 🔭	🕞 🔢 l 🗖 🗸 🖌	A - 🖂	Arial		✓ 10	✓ В I Ц	<u>A</u> - & -
· • • • • • • • • • • • • • • • • • • •							ACC COCONTIN					
Editor • ► ►			日中へろ									
Of Contents 7 ×												
9 😔 🖳 🗄 🗄	∷ • 뭡 •	h	X 🖧 🖸									
Jayers	temporary_hillslo	pe_table_	step5									
🗉 🚞 K:\Projects\10-04818-000\Shape\From_SueMille	BURNSEV	OID_1	FID_distur	Join_Count	Join_Cou_1	FID_hillsl	ID	GRIDCODE	FID_Landty	ld_1	Land_type	ORIG_FID
🗄 🗌 dem.tif	• 0	7386	11	0	0	24386	12	35182	2	0	Pasture	11
burn_severity.img	0	7290	14	0	0	24406	15	35356	2		Pasture	14
K:\Projects\10-04818-000\Output	0	7095 7071	17	1	0	24423 24427	18 20	35315 35431	1		Young Forest Young Forest	17
temporary_hillslope_table_step5	- 0	70/1 7126	19	3	0	24427 24432	20	35431 35307	1		Young Forest	19
	0	7068	20	2		24440	22	35449	1		Young Forest	20
	0	7092	22	3	0	24441	23	35439	1		Young Forest	22
	0	7072	23	1	0	24442	24	35177	1		Young Forest	23
	0	7070	25	2		24449	26	35365	1		Young Forest	25
	0	7083 7115	26 28	0	1	24452 24467	27 29	35332 35301	2		Pasture Pasture	26
	0	6943	31	2		24467	32	35486	1		Young Forest	31
	0	6944	32	3	0	24500	33	35587	1		Young Forest	32
	0	6907	33	1	1	24506	34	35588	1		Young Forest	33
	0	6871	34	0	0	24507	35	35383	2		Pasture	34
	0	6870 6482	35 38	1	1	24513 24584	36 39	35355 35505	2		Pasture Pasture	35
	- 0	6755	30	1	0	24504 24602	40	35348	2		Pasture	30
	- 0	6417	40	3	0 0	24602	41	35348	3		wetland	40
	0	6231	41	1	1	24617	42	35636	2	0	Pasture	41
	0	6229	42	0	0	24617	43	35636	3		vvetland	42
	0	6260	43	3	1	24635	44	35475	1		Young Forest	43
	0	6261 6439	44 45	1	0	24635 24658	45 46	35475 35596	3		Vetland Young Forest	44
	- 0	5923	46	1	0	24665	40	35647	2		Pasture	46
	0	5397	47	1	2	24740	48	35624	1		Young Forest	47
	0	5239	48	1	1	24760	49	35784	3		wetland	48
	0	5405	49	1	2	24774	50	35617	1		Young Forest	49
	0	5118 5043	52 53	1	1	24798 24798	53 54	35820 35820	2		Pasture wetland	51 52
	- 0	6635	53	1	0	24796	55	35534	2		Pasture	52
	0	5736	55	1	0	24803	56	35734	2		Pasture	54
	0	5389	56	1	1	24807	57	35915	2	0	Pasture	55
	0	5149	57	1	1	24809	58	35817	2		Pasture	56
	0	5097 4877	58 59	2	2	24814 24839	59 60	35606 36025	2		Pasture Vouna Forest	57 58
	- 0	4877	59	1	1	24839	60	36025	1		Young Forest wetland	58
	0	4852	63	1	1	24045	64	36010	3		wetland	61
	<			- <u>-</u>								

In this example, you will notice a field six columns to the right called **ID** that contains sequential unit ID numbers. To point the **Input Treatment Unit ID Field** prompt towards the **ID** field in the example dataset, you would replace [**UNITID**] with [**ID**] in brackets.

Step 6: Export Hillslope Data	
Input Table	Input Treatment Unit ID
temporary_hillslope_table_step5 🗾 🛃	Field
Input Treatment Unit ID Field	
[ID]	Input the field from the table
Input Soil Texture Field	generated in Step 5 that represents the hillslope Unit ID.
[SOIL_TYPE]	Enter the field name in
Input Upper Treatment or Vegetation Type Field	brackets.
[UTREAT]	
Input Lower Treatment or Vegetation Type Field	
[LTREAT]	
Input Adjacent Stream Name Field	
[ADJ_STRM]	
Input Stream Tributary Field	
[TRIB_TO]	
Delete Fields	
UGRD_TP	
UGRD_BTM	
	~
Cancel Environments << Hide Help	Tool Help

The same process of looking up column names in your output table and entering them into the Step 6 input fields that they correspond to should be repeated for all six inputs. If you do not wish to point a field from your output table to a Step 6 input field, simply leave the bracketed field name defaults that are present when you open the user interface.

It is very common when joining multiple datasets in GIS to have very similar field names occur within the same table. For example, your output table might contain one called **Land_Typ** and one column called **Land_Typ_1**. It is important to open up your output table to look closely at what field name you are intending to use before you enter it into the Step 6 user interface.